



Thanks for purchasing our **KOSO Regulator**, before operating this unit read carefully this instruction sheet and retain it for future reference.

## ▲ NOTICE

1. For installation, please follow the steps described in manual. Any damage caused by wrong installation shall be imputed to the users.
2. Don't break or modify the wire terminal. To avoid the short circuit, please don't pull the wire when installing.
3. Do not disassemble or change any parts.


## Electrical specification

1. Input voltage range : 12~30V (AC/DC)
2. Output voltage range : DC 12~15V
3. Max Load : 6W

## Function

The regulator is made to avoid meter damage caused by unstable power from the vehicle.

## 1 ACCESSORY



**NOTE** Please make sure all the accessories are included when you open the box.

## 2 Installation instruction

